



# Berry Go Round Instructions

## Equipment Needed:

Berry Go Round Unit on its Trailer

## Transportation:

**Note: One 2" trailer ball is required to tow the BGR.**

1. Make sure that the cloth cover is securely in place, with the zipper fully zipped over the front door area.
2. Attach the BGR to the 2" ball on your vehicle.
3. Crank all 4 trailer stands upward a few inches so all 4 are off the ground.
4. Raise all 4 trailer stands to their highest position by pulling pins out, raising interior jack stand and re-pinning in the highest hole for transporting BGR.
5. Ensure the traveling safety "T" shaped lock pin under the rear of the BGR is in the locked position. Pull it down and allow to go up into the berry to lock the berry so it does not rotate during transport.
6. Connect the trailer lights and safety chains to your vehicle and you are ready to travel.

## Set Up Instructions:

1. Find a level area approx 25' x 30' to set up the BGR.
2. Riders will enter/exit BGR from the rear (opposite side of trailer tow arm) so make sure to place back of BGR facing the way you want.
3. Let down all 4 trailer stands and pin them at their lowest point so they will support BGR (like when you picked it up.) Make BGR as level as possible by hand cranking the 4 stands to their proper level.
4. Disconnect lights and hitch from your vehicle and remove vehicle.
5. Unzip and remove cloth cover by carefully working bottom upward evenly. Store cover in safe place.
6. Notice the silver, aluminum fence pieces at front of trailer. Locate the taller, entrance/exit piece with the gate. Stand upright 8'-10' in front of the BGR door and start connecting the other fence pieces to entrance. Place entrance sign into the two holes on top of gate piece. Ground stands have holes that accept the bottom on each fence piece. (Ground stands are located in front of trailer in a recessed area by fences.) Use stands that have 2 holes for all fencing but where you want the light poles. Three hole fence stands are for the light poles. If using at night: place light poles in third hole and use attached bracket to secure them to the fencing for stability. Set the two light poles towards the front and point at the BGR entrance. Plug black power cords (included) into each light and plug into receptacles by gray power / breaker box.
7. Plug the main power cord from the BGR into the bottom of the breaker box next to the wheel well and connect to nearest power source.

- Unlock the traveling safety lock “T” pin under the rear of the BGR. Twist it to unlock and pull it down and lock it again in the down position so BGR rotates freely.

**Operating Instructions:**

- Locate the door locking pin (a thin, flat yellow metal piece to the left of the door) that rotates up and down. Flip it up to unlock. Flip it back down to lock.
- Twist the handle in the center of the door and let down the stairs all the way to the ground.
- Allow up to 6 kids or 4 adults to enter the BGR via the stairs.
- Raise and lock the stairs/door by reversing the process in steps 1 and 2 above.
- Locate the yellow box power cord with the start/stop buttons. Pressing the “start” button frees ride to operate. Tell the occupants to start spinning the berry by turning wheel in center of berry—like the Tea Cups at Disneyland. The timer is pre-set at 45 seconds per ride. Once 45 seconds has elapsed, the auto brake will slow down and stop the BGR.
- If you need to stop the ride before timer expires, simply press the “stop” button in yellow control box. (You may need to push “start” button again and physically turn the BGR to the proper load/unload position.)

**Notes:**

- Do not let occupants inside BGR stick their hands or feet outside the Berry opening!
- Do not let occupants play with safety lock and door opening mechanism while ride is operating!
- Do not let people waiting to ride inside the fenced area until previous riders have left area.
- Keep people away from the rear of the BGR while it’s operating.
- If it rains, stop ride and exit riders, and unplug unit from power source.
- If occupant is screaming bloody murder, stop ride, let them out, make fun of them.

**Returning the Berry Go Round**

All parts listed below must be returned in good working condition. Any parts missing or broken will be charged at the price listed.

<b>U</b>	<b>Qty</b>	<b>Item</b>	<b>Price</b>
'	1	Berry Go Round	\$ 19,000.00
'	6	Fence & Gate	3649.00
'	5	Bases for Fencing	
'	2	Lights	665.00
'	1	Cover	500.00
'	1	Spare Tire	
'	1	Halogen Bulb for Lights	



[www.partylandutah.com](http://www.partylandutah.com)

*Trouble shooting hints, power requirements, and additional copies of this form may be reprinted from the above website.*