



# Dunk Tank Instructions

## Equipment Needed:

- 1 Dunk Tank w/ Window
- 1 Target Arm
- 1 Target arm Face
- 3 Tennis Balls
- 1 Backdrop Tarp (attached)
- 1 Tow Arm /Bar
- 2 Tow Arm Bolt
- 2 Tow Arm Pins
- 1 Ball Hitch Clip / Lock
- 1 Drain Valve Assembly
- 2 Bungee Cords

## Transportation:

1. Hook dunk tank tongue bar to vehicle using **YOUR 2"** trailer ball hitch.
2. Close latch firmly, attach hitch clip and attach security chains.
3. Check yellow target frame (wing)--make sure it's secured around tank with 2 bungee cords.
4. Lock seat in "up" position.
5. Place target arm, target, and tennis balls in vehicle.
6. Only transport dunk tank during daylight hours.
7. PartyLand assumes no liability for highway violations of any kind.

## Set Up Instructions:

1. Unhook dunk tank from your vehicle.
2. Set tank on level area--grass is best. Make sure tank is away from any electricity.
3. Remove the TWO pins from the hitch bolts and remove bolts from the trailer tongue bar.
4. Slide out trailer tongue bar; re-insert BOTH hitch bolts and pins back into tongue bar now.
5. NOTE: trailer and dunk tank are one unit, DO NOT TRY TO SEPARATE!!!
6. Carefully lift tank into an upright position. Set tongue bar behind tank.
7. DO NOT allow tank to fall into position-damage to tank may occur (leakage).
8. Unhook bungee cords holding yellow target frame (wing). Swing out into position.(See picture).
9. Place a brick, rock, etc at base of wing to keep from moving. Wind, balls thrown, may move wing back and bend target arm.
10. Check drain valve assembly (trailer side of tank at bottom) and make sure it's in the closed position (red handle is not parallel with drain pipe).
11. NOTE: begin filling tank now--500 gallon tank takes approx 1-2 hours to fill (time varies depending on hose size, water pressure, etc.) Fill to within 6"-8" of the top of tank. (Do NOT fill unless an adult can remain with the filled tank at all times).
12. Install target arm: place flattened end of target through the metal guide and under trigger mechanism of vice-grip. Place the other ("L" shaped) end through the square tubing on the wing and through hole in yellow backdrop. Make sure target arm drops into slot on the side of wing frame. Insert target face (from the front of yellow tarp) onto the target arm so pin holes line up. Clip face to target arm. Place one hand on seat and press down while moving target arm against trigger mechanism. Turn adjusting screw on vice-grips to adjust the amount of force required to release the seat.

## Operating Instructions:

1. NO non-swimmers or people less than 5' tall in the tank, only ONE person at a time on or in tank
2. Wear tennis shoes to avoid slipping while climbing on tank--use built-in ladder on side of tank or separate ladder.
3. NEVER stand on the seat!
4. DO NOT operate dunk tank during a storm.
5. ALWAYS drain tank during periods of unsupervision.
6. Check to see that seat is locked into "up" position.
7. While on seat, keep hands on knees & sit forward. When coming out of water, move to front of tank to avoid hitting head on seat.
8. Use only TENNIS BALLS, NEVER baseballs, softballs, etc--they could damage tank, participants, spectators, etc.
9. Don't hit target with hands--you may injure an unsuspecting participant.
10. Show person being dunked how to re-set the seat and target arm before getting out--this will speed up operation.
11. Monitor water level and refill periodically if needed.
12. Only throw balls when person being dunked is properly seated and ready.

## Take Down:

1. Open drain valve (red handle is parallel with drain pipe) and let water completely drain.
2. Remove target and target arm, clip back together once removed from frame.
3. Fold yellow target wing back against tank and secure with 2 bungee cords.
4. Carefully tip dunk tank over on its wheels. Make sure seat is locked upright.
5. Insert trailer tongue bar and insert BOTH hitch bolts and pins.
6. Attach to vehicle as per instructions in section one.
7. Double check ropes and chains to make sure they are secure.
8. Place target arm, target and tennis balls in vehicle.

## Returning the Dunk Tank

Upon return this rental item must have all the following parts with it, in working order. Parts that are broken or missing will be charged at the price listed.

<b>U</b>	<b>Qty</b>	<b>Item</b>	<b>Price</b>
'	1	Dunk Tank w/ Window	\$ 4,800.00
'	1	Target Arm	21.00
'	1	Target arm Face	21.00
'	3	Tennis Ball (each)	1.00
'	1	Backdrop Tarp	135.00
'	26	Tarp Bunjee Clips (each)	3.50
'	1	Plastic Mesh-12'	15.00
'	1	Tow Arm /Bar	135.00
'	2	Tow Arm Bolts (each)	7.50
'	2	Tow Arm Cotter Pins	1.00
'	1	Ball Hitch Clip / Lock	4.00
'	1	Drain Valve Assembly	25.00
'	2	Bungee Cord / Rope	10.00

**A Cleaning Fee of 15.00 will be assessed on any rental item that is not cleaned upon return.**



[www.partylandutah.com](http://www.partylandutah.com)

*Trouble shooting hints, power requirements, and additional copies of this form may be reprinted from the above website.*