



# High Striker Rental Instructions

## Equipment Needed:

- 1 High Striker Unit
- 1 Mallet

## Set Up Instructions:

1. Locate appropriate area for striker and unhook from tow vehicle. Area must be level! Unit is 17' high and 6' wide. Allow plenty of room for unit and participants swinging mallet. Attaching pennant flags to top of unit now adds to the festive atmosphere of the activity.
2. With 2 or 3 strong people, start raising the bell end of unit skyward.
3. Make sure unit stays balanced as it goes upward. Once tower is vertical, release pins on both balancing legs and lower legs to ground level.
4. Re-attach lock chains on support legs to frame.
5. Drive 4 stakes through rings on frame.

## Operating Instructions:

1. The ease/difficulty of hitting the bell is adjustable! Turn the bolt clockwise to decrease difficulty, counter clockwise to increase difficulty.
2. Player swings three times and hits rubber pad launching metal bell ringer towards bell.
3. If bell is rung, player wins! Any other height does not win.

**NOTE:** Do not use plastic mallet to drive stakes. Please use a metal sledge hammer.

## Returning the High Striker

All parts listed below must be returned in good working condition. Any parts missing or broken will be charged at the price listed.

<b>U</b>	<b>Qty</b>	<b>Item</b>	<b>Price</b>
'	1	Adjuster	\$ 30.00
'	1	Arm	135.00
'	1	Bell	90.00
'	1	Hammer	215.00
'	1	Hitch	135.00
'	1	Hinge	120.00
'	1	Hub cap	30.00
'	1	Puck/ Slider/ Ringer	40.00
'	1	Rail	90.00
'	1	Rubber Pad, large	55.00
'	1	Spring	12.00
'	1	Steel Spring	55.00
'	1	Striker Base	560.00
'	1	Tire	55.00



[www.partylandutah.com](http://www.partylandutah.com)

*Trouble shooting hints, power requirements, and additional copies of this form may be reprinted from the above website.*