



Lighting Equipment Instructions

Equipment Needed:

- Black Light
- Strobe Light
- Police Light
- Scanner Light
- Mirror Ball
- Mirror Ball
- Electric Motor (to turn ball)
- 2 Pin Spotlights (1 w/ 8" mirror ball)

Operating Instructions:

BLACK LIGHT:

1. Take light fixture out of box and plug power cord into wall outlet.
2. Press down and hold the white rocker switch until the purple bulb starts to light up.
3. Let go of switch and light will turn on completely.
4. Make sure equipment has cooled before placing it back inside box.

STROBE LIGHT (9" or 6"):

1. Plug power cord into wall outlet.
2. Turn the switch on the back of the light to the "on" position.
3. Turn the knob clockwise to increase the rate at which the light flashes. Counter clock-wise will decrease the rate of the flash.
4. Make sure equipment has cooled before placing it back inside any packaging.

POLICE LIGHT & SCANNER LIGHT:

1. Plug power cord into wall outlet.
2. Light will begin operating immediately.

MIRROR BALL:

1. Securely attach electric turn motor to hook or stable wire near ceiling. Try to place motor near the center of the room in which the ball will be operating.

2. Run an extension cord to the turn motor and secure it out of the way. Ensure that the cord is long enough, and that the hook or wire is capable of holding the weight of the equipment.
3. Carefully attach the mirror ball to the hook on the downward side of the turn motor, and plug in the power cord. Make sure that the ball is rotating properly.
4. Plug in the spot light(s) and position them to shine onto the ball. Lights can be suspended from the ceiling or placed in any position that will give you the most direct beam to the ball.
5. Make sure equipment has cooled before placing it back inside any packaging.

**If above steps can't get machine working, call PartyLand immediately:
1-801-489-7777 or 1-800-489-7797**

Do NOT attempt to repair machine in any way. Any damages to the machine due to such an attempt will be charged to you.

WARNING / DANGER

- All of these products require electricity in order to operate. Use carefully to prevent accidental shock or electrocution.
- Light products produce heat and should be kept away from children.

Returning the Lighting Equipment

All parts listed below must be returned in good working condition. Any parts missing or broken will be charged at the price listed.

U	Qty	Item	Price
'	1	Black Light	\$ 30.00
'	1	Flourescent Bulb	8.50
'	1	Strobe Light 9"	105.00
'	1	Bulb	9.10
'	1	Strobe Light 6"	85.00
'	1	Bulb	5.32
'	1	Police Light	50.00
'	1	Dome	10.50
'	1	Light Bulb	3.50
'	1	Mirror Ball	71.50
'	1	Hanging Turner	19.50
'	1	Spotlight	34.50



www.partylandutah.com

Trouble shooting hints, power requirements, and additional copies of this form may be reprinted from the above website.