



Punch Fountain Rental Instructions

Equipment Needed:

Electric Punch Fountain

Operating Instructions:

1. Place your punch mix into fountain bowl.
2. **NOTE:** punch high in pulp will clog pump--**DO NOT USE** or thin mixture with a soda, juice or other mixer that will dilute the high pulp concentration. **NOTE:** Soda will lose its carbonation very quickly as it is pumped through the fountain.
3. Plug fountain into wall.
4. Turn on fountain by using the toggle switch at base of unit.
5. Within 1-2 minutes punch should come out all four arms at top of fountain.

Trouble Shooting: If unit stops working:

- Check to see if unit is plugged in to a working outlet.
- Check breaker switch in breaker box (inside building) to make sure it hasn't switched "off." (Look for orange color in clear window of switch--if orange appears, turn switch back to "on" position.)

Cleaning the Machine

1. Immediately after use, and with all punch out of fountain, fill bowl with hot water.
2. Turn on pump and let run for several minutes.
3. If water is still colored or remaining pulp is still noticeable, empty bowl and put fresh, hot water in again. Do as often as necessary to clean out unit.
4. Do not clean outside of bowl with anything that will scratch the finish. Wipe with non-abrasive cloth rag and warm water.

**If above steps can't get machine working, call PartyLand immediately:
1-801-489-7777 or 1-800-489-7797**

Do NOT attempt to repair machine in any way. Any damages to the machine due to such an attempt will be charged to you.

WARNING / DANGER

- Machine must be properly grounded to prevent electrical shock to personnel.
- Do NOT immerse this equipment in water.
- Always unplug the equipment before cleaning or servicing.

Returning the Rental Item

All parts listed below must be returned in good working condition. Any parts missing or broken will be charged at the price listed.

U	Qty	Item	Price
'	1	Fountain	\$ 999.00+
'	1	Bulb	1.25
'	1	Motor	49.50
'	1	Filter	

A Cleaning Fee of 15.00 will be assessed on any rental item that is not cleaned upon return.



www.partylandutah.com

Trouble shooting hints, power requirements, and additional copies of this form may be reprinted from the above website.