



# Sound Equipment Rental Instructions

## Equipment Needed:

Bull Horn

or

Mini- Vox (Porta-P.A.)

Microphone

Carry Case

## **BULL HORN:**

1. Hold horn in hand pointing it away from your face.
2. Pull the trigger with fore finger and speak into the back of the horn.
3. Adjust the loudness of the Bull Horn by turning the dial at the back of horn.

**NOTE:** Turning the unit up all the way can damage the components. Feedback from the horn means it is turned TOO LOUD.

4. Horn has a siren option on the left side of the horn. Turn the switch to activate the siren.

## **MINI-VOX (Porta-PA):**

1. Unpack unit from carry bag.
2. Turn main switch on the unit to the OFF position.
3. Get the microphone from the interior pocket and plug it into the microphone jack at the top rear of unit.
  - a. Plugging microphone into unit while it is on can result in loud feedback if volume is too high.
4. Turn main switch on the unit to the ON position. Turn the switch on the microphone to the ON position.
5. Place shoulder strap over shoulder to carry unit, or place it on flat dry surface for table-top use.

6. Hold microphone to mouth and speak. Adjust volume as needed.
  - a. Avoid feedback by not placing the microphone in front of, or near the speaker.

**NOTE:** Turning the unit up all the way can damage the components.

7. Turn unit off when not in use.

**Do NOT attempt to repair machine in any way. Any damages to the machine due to such an attempt will be charged to you.**

**WARNING / DANGER**

- Use carefully to prevent accidental shock or electrocution.
- Use caution when using near open bodies of water (lakes, pools, etc.)
- These are not toys. Please use common sense when operating this equipment near children.

**Returning the Sound Equipment**

All parts listed below must be returned in good working condition. Any parts missing or broken will be charged at the price listed.

<b>U</b>	<b>Qty</b>	<b>Item</b>	<b>Price</b>
'	1	<b>Bull Horn</b>	\$ 174.95
'	8	Batteries	
'	1	<b>Porta-P.A.</b>	\$ 250.00
'	9	Batteries	
'	1	Microphone	
'	1	Carrying Case	50.00



[www.partylandutah.com](http://www.partylandutah.com)

*Trouble shooting hints, power requirements, and additional copies of this form may be reprinted from the above website.*